

## Remote control


Z473A/BC/DE/F

Z483/Z487/Z489

The remote control may not be taken into the wheelhouse, engine room or living area.

This is to avoid connection problems that can cause an emergency stop.

The **red STOP button** may only be used in case of an emergency (press and hold for 3 sec) or, if agreed upon with DISPATCH, the **red STOP button** can be used for a ship stop.



Press the **green dead man's handle** gently once every 8 min.

Every 8 min a light will flash on the quay for 2 min.

Afterwards a horn sounds for 30 s.

If you do not press within this period of time, the loading/discharging stops.